

## V1S 固件说明

- 一、请使用神牛固件升级软件 G3 打开该固件进行升级。 G3 可在官网下载。
- 二、版本号查看方法：开机后按 “MENU” 按键，进入 C.Fn 菜单。右上角显示 Ver x.x 为版本号。
- 三、版本说明：

版本	更新内容	日期
V1.8	兼容徕卡引闪器 XProII 无线系统	2022-08-16
V1.6	1、替换字符,RX 替换 Slave。	2020-07-16
V1.5	1、 增加 mode 按键锁住功能（长按 MODE 按键 2 秒）	2020-06-20
V1.4	1、 改善热保护系统。 2、 调整 LED 控制方式。 3、 增加打开相机 WL 模式时有警示。	2019-08-17
V1.3	1.优化 V1S 和 sony 相机之间的通讯；	2019-06-05

注：详细规格请在官网（[www.godox.com.cn](http://www.godox.com.cn)）下载最新说明书。

## V1S Firmware Release Note

1. Please update the firmware with Godox firmware update software G3. G3 can be downloaded on the official website.
2. How to check the version number: press the “Mode” button to turn on the gear; the LED screen will show U-xx, and xx is the version number.
3. Version Instructions:

Version	What's New	Date
V1.8	To add compatibility with Flash Trigger for Leica --- XProII Wireless System	2022-08-16
V1.6	1. To replace the display sign “Slave” with “RX”.	2020-07-16
V1.5	1. To add the lock function of the mode button (press the MODE button for 2 seconds)	2020-06-20
V1.4	1. To improve heat protection system 2. To adjust the LED control mode 3. To add a warning when opening the camera's WL mode.	2019-08-17
V1.3	1. Optimize the communication between V1S and Sony cameras;	2019-06-05

**Note: For more details, please download the newest instruction manual on the official website:**  
[www.godox.com](http://www.godox.com).

