

## AD300ProII 发射器固件说明

- 一、请使用神牛固件升级软件“Godox G3 Windows V1.1”或 Godox G3 macOS V1.1 打开该固件进行升级。软件可在官网上下载。
- 二、版本号查看方法：设备开机，进入菜单设置，在设备信息中查看固件版本号（如 1.1 版本：V1.1）。
- 三、版本说明：

版本	更新内容	日期
V1.05	1、调整蒙版功能（周期次数增加到 8 次，可多次引闪） 2、修复色温模式时，个别引闪器引闪档位会偏移的问题。 3、修复无线关闭组别时，快调节减档位会显示乱码的问题。	2025-12-22
V1.0	初始版本	V1.0

注：详细规格请在官网（[www.godox.com.cn](http://www.godox.com.cn)）下载最新说明书。

**AD300ProII Firmware Instruction**

1. Please update the firmware with Godox firmware update software Godox G3 Windows V1.1 or Godox G3 MacOS V1.1. Both can be downloaded from the official website.
2. How to check the version number: Turn on the gear, and enter the menu settings to check the version number in Device Info. (e.g., Version 1.1: V1.1).
3. Version Description:

Version	What's New	Date
V1.05	<ol style="list-style-type: none"><li>1. Adjusted the Mask function (cycle count increased to 8, allowing multiple flash)</li><li>2. Fixed an issue when the trigger power level could shift in Color Temperature mode with certain transmitters.</li><li>3. Fixed garbled display when decreasing power levels using quick adjustment after disabling wireless groups.</li></ol>	2025-12-22
V1.0	Initial Version	V1.0

**Note:** For more details, please download the latest instruction manual from the official website:  
<https://www.godox.com/>